

# ERA

## Fortress Maximum Security Cylinder Fitting Instructions

### Installing a Fortress Maximum Security Cylinder

This cylinder offers 3\* resistance to many kinds of cylinder attack.


To be used in conjunction with a door handle to ensure enhanced resistance to all commonly used attack methods.

### How to change your cylinder

On the open edge of the door look for the larger screw which falls in line with the bottom of the cylinder and remove screw.

With the key inserted into the cylinder, turn slightly while pulling to enable the cylinder to be removed.

To replace the cylinder reverse the above procedure.



### Cylinder Size Guide

- A** Measurement from the centre of the cam to point A (refer to above diagram)
- B** Measurement from the centre of the cam to point B (refer to above diagram)

**Note:** Your cylinder may be longer on one side than the other